

SIGNAL[™] 5

Quick Start Guide

Follow these steps to install SIGNAL 5 and other modules:

1. This document can be downloaded from the Support page of <http://www.engdes.com/>
2. **SIGNAL 5 must be installed before any SIGNAL add-ons, such as Event Analyzer.**
3. To install SIGNAL 5, insert the SIGNAL 5 CD or download the installer from the web <http://www.engdes.com/sigwin/support/download/sig5/index.html>
4. Open **sig5_install.pdf** in the download file or CD, which contains detailed installation instructions. **Follow those instructions to perform the installation.**
5. After installing SIGNAL 5, install any optional SIGNAL add-ons, such as Event Analyzer. **RTS and Event Detector are automatically installed by the SIGNAL 5 installer.**
6. To install Event Analyzer, insert the Event Analyzer CD or download the installer from the web <http://www.engdes.com/sigwin/support/download/evanal5/index.html>
7. Execute the Event Analyzer setup program **evanal_xxx_setup.exe**, where "xxx" is the version number. Event Analyzer will be installed in the same folder as SIGNAL.
8. If your system includes a SIGNAL I/O card, **you must install I/O driver support for that card.** Follow the instructions for the card manufacturer, provided in the **Installation** chapter of the *SIGNAL I/O Hardware Guide*, which can be downloaded from <http://www.engdes.com/sigwin/support/support.html> For National Instruments cards, turn to the section "National Instruments – Current Version" in this guide.
9. SIGNAL can sometimes have trouble finding its Help file on Windows Vista and later. If this occurs, see "Troubleshooting" in **sig5_install.pdf**.
10. On Windows Vista and later, sound files cannot be dragged into SIGNAL from Windows Explorer. The substitute Explorer++ program is highly recommended for this purpose. For details, see "SIGNAL and Windows Vista/7/8/10" in **sig5_install.pdf**.

Engineering Design

262 Grizzly Peak Blvd
Berkeley, CA 94708 USA

Tel / Fax 510-524-4476
www.engdes.com